

APPLICATION NOTE


Free Time Zone access for all cards and FOB which are not enter into PROS CS

AO61

Free Time Zone access for all cards and FOB will allow to all the users to use their cards/FOB to enter the premises without registration at the PROS CS. After Free Time Zone access expired access for all cards and FOB which are not enter into PROS CS is forbidden.


1. Open the Controller/Properties/Time zone.

Define requested Time zone, and then click on "Save& Exit" Tab.




2. Go to the Door witch need to be set. Select Properties/Time zone.

Check Door enable section on predefined Time zone and click on "Save&Exit" Tab.



3. Go to reader associate to Door witch need to be set.

Click on Free Access Time Zone. Check section "Enable TZ" previously define at the Controller, then click on "Save&Exit" Tab.



Free Time Zone access for all cards and FOB which are not entered into PROS CS will be granted. After Free Time Zone access expired all cards and FOB access will be forbidden.